## **REMOTE PRO**


## PROGRAMMING INSTRUCTIONS




## **APC**

## **CODING TO SWING OR SLIDING GATE MOTOR**





**Sliding Gate** 



- 1. Open the cover of your motor to reveal the circuit board.
- 2. Press and release the learn button (see the appropriate red box in the images above).
- 3. Press any button you wish to operate your motor on your new remote for 2 seconds.
- 4. Wait 2 seconds.
- 5. Press the same button on your new remote again for 2 seconds.
- 6. Test your remote.