

REMOTE PRO

PROGRAMMING INSTRUCTIONS



CODING TO ARD GARAGE MOTORS

1. Press and release the “code” button and “.” will display on the bottom right of the screen
2. Press the button on your remote which you would like to operate your door for 2 seconds
3. Press the same button for 2 seconds
4. Wait 5 seconds and test



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

