
REMOTE PRO

PROGRAMMING INSTRUCTIONS



ATA GATE MOTOR

PROGRAMMING NEW REMOTE INTO DCB05 CONTROL BOARD



- 1. Press the "Next" button. The screen will display "Menu 1 Code Transmitter"
- 2. Press the "SET" button. The screen will display "Press TXR"
- 3. Press any button on your new remote for 2 seconds. The screen will display "Press TXR Again".
- 4. Press the same button on your new remote again for 2 seconds.
- 5. Press the "SET" button.
- 6. Press the "EXIT" button.
- 7. Test your remote.

