

REMOTE PRO

PROGRAMMING INSTRUCTIONS



E-GUARD

Button 1: Pressed to operate a single gate.

Button 2: Pressed to operate double gates.

Button 3: Pressed for alarm output.

Button 4: N/A

PROGRAMMING YOUR REMOTE

1. Press the LEARN button on the control board for 1 second. The LED indicator will turn OFF. The motor is now in learning mode.
2. Press any button on the new remote control for 2 seconds. The digital display will show the remote number. The LED indicator on the board will flash four times with one buzzer sound to indicate successful programming.

Note: After pressing the LEARN button, if no signal has been received within 5 seconds the motor will exit LEARN mode.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

