

REMOTE PRO

PROGRAMMING INSTRUCTIONS



INTEL DOORS

PROGRAMMING YOUR NEW REMOTE

1. Press and immediately release code button located on motor
2. Press the button on the new remote control you wish to code to the motor twice
3. Test the remote



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

