

REMOTE PRO

PROGRAMMING INSTRUCTIONS



CODING A LIFTAWAY LA238 REMOTE

1. Locate the code set button on the garage door opener control panel.
2. Press the code set button until the coding light illuminates indicating that the opener is in remote learning mode.
3. Press any one of the four remote buttons two times. The coding light on the opener will turn off. Your remote is now programmed.



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

