

REMOTE PRO

PROGRAMMING INSTRUCTIONS



MOC OPENERS

1. Press on the Code Button once and immediately release
2. Press the new remote's button which you would like to use to control the door twice
3. Press the button on the new remote to test operation of the door



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

