REMOTE PRO

PROGRAMMING INSTRUCTIONS



CODING TO TDA GARAGE MOTORS

- 1. Press and release the "code" button and "." will display on the bottom right of the screen
- 2. Press the button on your remote which you would like to operate your door for 2 seconds
- 3. Press the same button for 2 seconds
- 4. Wait 5 seconds and test

