

REMOTE PRO

PROGRAMMING INSTRUCTIONS



BOSS

WALL MOUNTED MOTORS

1. Remove the faceplate of your wall mounted motor control panel. On the bottom centre of the grey faceplate will be a tiny slot that allows you to insert a flat screwdriver to remove the cover.
2. Once faceplate is removed, locate the radio Learn/Code Set button (indicated in the photo below by the small black button in the red circle) and push it once. A light will illuminate to indicate your motor is ready to accept a new remote.
3. Press any button on your new remote that you wish to operate the door once and release. The learning light on the motor control panel will blink to indicate the code has been learnt.
4. Push the Learn/Code Set button once and release.
5. Test the remote and place the faceplate back onto the motor control panel.



Please refer to page to for ceiling mounted motors

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.



REMOTE PRO

PROGRAMMING INSTRUCTIONS



CEILING MOUNTED MOTORS

1. Locate the Radio Set/Code Set/Learn hole. This is usually located on the rear of your motor.
2. Once located, insert a small pointed object into the hole and push the button once. A light will illuminate to indicate your motor is ready to accept a new remote.
3. Press any button on your new remote that you wish to operate the door once and release. The learning light on the motor will blink to indicate the code has been learnt.
4. Press the Radio Set/Code Set/Learn button once and release.
5. Test the remote.



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

